

CURE REPORT

Systima Technologies 10809 120th Ave NE Kirkland, WA 98033

<u>Job</u> 103755

Program D11897

Equipment

Autoclave | Controller: S2601 Air TC1: S2600 | Air TC2: S2603 PT: S2599 | VT3: S2595

Part

49481-100 Rev. E DLAS LEFT, AS MOLDED Qty: 1

Cure


Start: 04-Feb-2021 | 10:16 AM Finish: 04-Feb-2021 | 2:50 PM Duration: 4h:34m

Cure Document

SPS-201 Rev. B Profile: CURE A2

PASS

All equipment used is calibrated and traceable to the SI through NIST.





CURE REPORT

Systima Technologies 10809 120th Ave NE Kirkland, WA 98033

Step Requirements Result **NCR**

Ramp Up

(PASS)

Start: 0.0 min Finish: 76.7 min Duration: 76.7 min

Temperature Max 295°F Temp. Ramp 5°F/min +0/-5°F/min Pressure: Max 60 psi

Pressure Ramp 1.5 psi/min ±1 psi/min

Vacuum Min -15 inHg

Terminate

Lag > 270°F AND > 40 psi

Temperature (°F)

Max 270

Temp. Ramp (°F/min)

Max 2.8 | Min 2.2 Pressure (psi)

Max 50.7

Pressure Ramp (psi/min)

Max 0.9 | Min 0.8

Vacuum (inHg)

Min -27.1

Dwell

(PASS)

Start: 76.8 min Finish: 214.0 min Duration: 137.2 min Temperature 275°F +20/-5°F

Pressure: 50 psi ±10 psi

Terminate

Lag < 270°F AND After 120 min Temperature (°F)

Max 281 | Min 278 | Avg 279 Pressure (psi)

Max 50.6 | Min 47.2 | Avg 49.9

Ramp Down

(PASS)

Start: 214.2 min Finish: 256.7 min Duration: 42.5 min Temperature Max 295°F

Temp. Ramp -5°F/min +10/-0°F/min

Pressure: 50 psi ±10 psi **Terminate**

Lead < 150°F

Temperature (°F)

Max 270

Temp. Ramp (°F/min)

Max -2.7 | Min -3.0

Pressure (psi)

Max 49.8 | Min 48.1 | Avg 49.2

Ramp Down **Pressure**

(PASS)

Start: 256.8 min Finish: 273.2 min Duration: 16.3 min Temperature Max 150°F

Pressure: Max 60 psi

Pressure Ramp -10 psi/min +15/-0 psi/min

Terminate

< 5 psi

Temperature (°F)

Max 138

Pressure (psi)

Max 49.5

Pressure Ramp (psi/min)

Max -1.9 | Min -4.0