

CURE REPORT

Systima Technologies 10809 120th Ave NE Kirkland, WA 98033

<u>Job</u> 103454

Program D11765 <u>Part</u>

55010-100 Rev. C GREMLINS SHROUD (AS MOLDED) Qty: 1 <u>Cure</u>

Start: 03-Feb-2021 | 8:41 AM Finish: 03-Feb-2021 | 3:21 PM Duration: 6h:40m

Equipment


Autoclave | Controller: S2601 Air TC1: S2600 | Air TC2: S2603 PT: S2599 | VT2: S2598 VT3: S2595

FAIL

Cure Document

SPS-201 Rev. B Profile: CURE A4

All equipment used is calibrated and traceable to the SI through NIST.



Completed By:	Andrei Branga	Date:	2/3/2021
OΔ Signoff·		Date:	



CURE REPORT

Systima Technologies 10809 120th Ave NE Kirkland, WA 98033

Step Requirements Result NCR

Temp Ramp

(FAIL)

Start: 0.0 min Finish: 63.2 min Duration: 63.2 min Temperature Max 245°F Temp. Ramp 5°F/min +0/-10°F/min Pressure: Max 1 psi

> Vacuum Min -15 inHg <u>Terminate</u>

> > Lag > 205°F

Temperature (°F)

Max 228

Temp. Ramp (°F/min)

Max 2.9 | Min 1.6

Pressure (psi)

Max 55.7

Vacuum (inHg) Min -26.2

Temp Hold

(FAIL)

Start: 63.3 min Finish: 63.3 min Duration: 0.0 min Temperature 225°F ±20°F

Pressure: Max 2 psi Vacuum Min -15 inHg

Terminate

After 60 min OR > 2 psi Temperature (°F)

Max 228 | Min 205 | Avg 220

Pressure (psi)

Max 54.8

Vacuum (inHg) Min -27.3

Ramp Pressure

(PASS)

Start: 63.5 min Finish: 130.2 min Duration: 66.7 min Temperature 225°F ±20°F Pressure: Max 90 psi

Pressure Ramp 1.5 psi/min ±1 psi/min

Vacuum Min -15 inHg

<u>Terminate</u>

Time continued from previous step.

AND

Lead > 245°F

Temperature (°F)

Max 232 | Min 205 | Avg 228

Pressure (psi)

Max 80.7

Pressure Ramp (psi/min)

Max 0.7 | Min 0.6

Vacuum (inHg) Min -27.0

Ramp Up

(PASS)

Start: 130.3 min Finish: 167.2 min Duration: 36.8 min Temperature Max 370°F

Temp. Ramp 5°F/min +0/-6°F/min

Pressure: Max 90 psi

Vacuum Min -15 inHg

Terminate

Lag > 345°F AND > 70 psi Temperature (°F)

Max 348

Temp. Ramp (°F/min)

Max 3.6 | Min 2.2

Pressure (psi)

Max 80.7

Vacuum (inHg)

Min -26.5

Dwell

(PASS)

Start: 167.3 min Finish: 302.5 min Duration: 135.2 min Temperature 350°F +20/-5°F

Pressure: 80 psi ±10 psi Vacuum Min -15 inHg

Terminate

Lag < 345°F AND After 120 min Temperature (°F)

Max 358 | Min 345 | Avg 353

Pressure (psi)

Max 80.7 | Min 75.8 | Avg 80.2 Vacuum (inHg)

Min -26.1



CURE REPORT

Systima Technologies 10809 120th Ave NE Kirkland, WA 98033

Ramp Down

(PASS)

Start: 302.7 min Finish: 380.8 min Duration: 78.2 min Temperature Max 370°F Temp. Ramp -5°F/min +10/-0°F/min Pressure: 80 psi ±10 psi

> <u>Terminate</u> Lead < 150°F

Temperature (°F)

Max 349

Temp. Ramp (°F/min)

Max -2.1 | Min -3.0

Pressure (psi)

Max 79.5 | Min 76.5 | Avg 78.4

Ramp Down Pressure

(PASS)

Start: 381.0 min Finish: 399.5 min Duration: 18.5 min Temperature Max 150°F Pressure: Max 90 psi

Pressure Ramp -5 psi/min +10/-0 psi/min

<u>Terminate</u>

< 5 psi

Temperature (°F)

Max 141

Pressure (psi)

Max 78.7

Pressure Ramp (psi/min)

Max -4.0 | Min -4.1